

Leader Light s.r.o. M.Gorkeho 33 SK-052 01 Spisska Nova Ves Slovakia www.leaderlight.eu


USER MANUAL

LL ARC MINI LINE WHITE LL40 205 LL40 215 LL40 225

COMPLIMENTS ON YOUR PURCHASE!



All dimensions are in milimeters





Following items are included:

- LL ARC MINI LINE with 5m cable and 6pin LINE connector	1 pc.
- LL BRACKET MINI LINE FIX	1 pc.
- User manual	1 pc.

Additional items needed:

- LL ARC DRIVER
- DC power supply 24V
- Controller compatible with DMX
- Mounting accessories (adjustable bracket)
- Screws and washers M6

Content:

01 SAFETY INFORMATION

- 01.1 Risk of eyes damage
- 01.2 Protection from electric shock
- 01.3 Fire prevention

02 PRODUCT SPECIFICATION

02.1 Technical Specification

03 INSTALLATION

- 03.1 Unpacking
- 03.2 Physical installation
- 03.3 Electrical installation
- 03.3.1 Connecting to AC/DC power supply

03.3.2 Connecting to LL ARC DRIVER for intensity/colour control

04 MAINTENANCE

ENVIRONMENT



Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

01 SAFETY INFORMATION



WARNING!!!

Carefully read before installing, powering or servicing. Nothing to do if anything misunderstand! Installation can be done only by a qualified professional in accordance with relevant local codes.

01.1 Risk of eyes damage

- Do not look directly into LED lamps.
- Do not look into light beam from a distance of less than 40 cm (16 inches)!

01.2 Protection from electric shock

- Shut down power before installation or maintenance.
- Luminaries, Driver and recommended power supply must be installed by a qualified professional in accordance with relevant local codes. Only acceptable source of power and frequency that complies with local building and electrical codes to use
- Do not use or do not connect the products if the power cable, power plug or fixtures are any way damaged, wet, or if they are overheating.

 - Do not modify, alter, or attempt to service the LeaderLight appliance. Doing so will void the
- warranty
- Before removing or installing any cover or part of appliance disconnect from power.

Operation only with DC 24V source! By using a high voltage AC power supply-danger of electric shock!

01.3 Fire prevention

- Follow all safety consideration.
- Thermostatic switches or fuses never to bypass.
- Device never shield minimum distance around fitting must be 50mm (2 in.).
- LEDs never direct cover with filters or other materials.
- Allowing max. ambient temperature is 40°C (104°F).

02 PRODUCT SPECIFICATION

02.1 Technical Specification

•	
Lamp type:	1200mm: 96xW TOP LED (White) 600mm: 48xW TOP LED (White) 300mm: 24xW TOP LED (White)
Lifetime:	Long 100 000 hrs 60% degradation
View Angle:	120°
Control data Input:	1 channel 24V dimming
Power input:	1200mm: max. 8W 600mm: max. 4W 300mm: max. 2W
Power connection:	24V DC 5m cable with 6pin LINE connector
Net weight:	1200/600/300mm: 1kg/ 0,6kg/ 0,3kg
Dimensions LxΦ:	1200/600/300mm x 38mm without bracket
IP:	IP20
Ambient temp. (Ta):	Maximum 40°C
Cooling:	Conventional
Materials and finish:	End cups: plastic Cover: frosted PMMA
Installation:	Any position for ceiling, wall and surface-mounting

03 INSTALLATION

03.1 Unpacking

- Unpack carefully.
- This is electronic equipment and should be handled carefully.
- Damaged delivered package or if are any mechanical parts broken it must be claim immediately by the transport company. Photo pictures as evidence are valuable or

03.2 Physical installation

- Loading capacity of bearing area has to be at least 10 times the weight of all device clusters (luminaries, clamps, cables, ...).
- Hairbreadth from combustible materials is 0,5m.

03.3 Electrical installation



- To tackle all Safety Information- 01!
- You can suffer a dangerous electric shock by using a high voltage AC/DC power supply - by touching the AC/DC power supply wires inside LL ARC MINI LINE!
- LL ARC MINI LINE can be operated in two ways:
 - 03.3.1 LL ARC MINI LINE connecting to DC POWER SUPPLY for switch ON/OFF
 - 03.3.2 LL ARC MINI LINE connecting to LL ARC DRIVER for intensity and colour control

03.3.1 Connecting to DC power supply (Figure Nr. 1.1)

- LL ARC MINI LINE must be connected to the device- MW power supply IN:100-260AC/ OUT: 24V.
- It is not necessary to open fixture before connecting to MW power supply.

AC Power Supply Cord plug connections to MW Power supply:

Symbol	Pin	Wire Colour	Screw (US)
L	live	brown	yellow or brass
N	neutral	blue	silver
(_	ground (earth)	yellow/green	green

03.3.2 Connecting to LL LED DRIVER (Figure Nr. 1.2)

- For intensity and colour control is necessary connection with LL ARC DRIVER.
- It is not necessary to open fixture before connecting to LL ARC DRIVER.
- Before installing of LL ARC DRIVER carefully read USER MANUAL for LL ARC DRIVER.

Order code	Product name	I _c (A)
LL40 205	LL ARC MINI LINE White 300	1x0,08A
LL40 215	LL ARC MINI LINE White 600	3x0,16A
LL40 225	LL ARC MINI LINE White 1200	3x0,32A
Accessories:		
LL41 170	LL BRACKET ARC MINI LINE 300 ADJUSTABLE	
LL41 171	LL BRACKET ARC MINI LINE 600/1200 ADJUSTABLE	
LL41 150	LL BRACKET ARC MINI LINE FIX	

MOUNTING ACCESSORIES FIX BRACKET End cup - standard delivery with luminary - standard delivery with luminary AIMING POSSIBILITY The fixture could be aim to wish position with adjustable bracket.

04 MAINTENANCE

- To tackle all Safety Information- 01!
- Damage caused by inadequate cleaning or maintenance is not covered by warranty.

Adjustable bracket

- Regular cleaning is demand (dust, dirt, ...).

Maintenance policy:

- Unplug mains before maintenance and at least 10 minutes cool off
- Appliance do not illegal open or demount
 Clean-up dust only from outer surface (for ex. diffuser).
- Use vacuum or dumpy duster (warm water)
- Before reinstalling to check failure-free state no wet parts!

